

Ballast Check 2 Handheld Pulse Amplitude Modulated (PAM) Fluorometer


Natalie Dunn

Julie Kuo

Division of Aquatic Resources

11/14/2017

Ballast Water



Background

- Requirements of low levels of live organisms in ballast water discharge
 - Treatment systems
 - How to show compliance
- *In situ* active fluorometers measure phytoplankton photosynthetic efficiency
- Ballast Check 2 quick indication of gross exceedance of the compliance standard *in vivo*




Purpose

- Rapid assessment tool to measure ballast water compliance (10-50 μm organism)
- Provides ship operators or port authorities with indication of risk
- Assessment of ballast water treatment systems
- Precision & accuracy optimized for ballast water IMO D-2 regulations



Active Fluorescence

- Light energy \rightarrow chlorophyll a & b
 1. Photochemical quenching (photosynthesis)
 2. Non-photochemical quenching (heat for light protection)
 3. Emission as fluorescence radiation



Active Fluorescence

- Light energy \rightarrow chlorophyll a & b

1. Photochemical quenching (photosynthesis)

Excite electrons

$\text{H}_2\text{O} \rightarrow \text{H}^+ + \text{O}_2$ (PSII)


$\text{ADP} \rightarrow \text{ATP}$

$\text{NADP} \rightarrow \text{NADPH}_2$

$\text{CO}_2 \rightarrow \text{sugar}$


2. Non-photochemical quenching (heat for light protection)

3. Emission as fluorescence radiation




Active Fluorescence

- Light energy \rightarrow chlorophyll a & b
 1. Photochemical quenching (photosynthesis)
 2. **Non-photochemical quenching (heat for light protection)**
 3. Emission as fluorescence radiation




Active Fluorescence

- Light energy \rightarrow chlorophyll a & b
 1. Photochemical quenching (photosynthesis)
 2. Non-photochemical quenching (heat for light protection)
 3. **Emission as fluorescence radiation**
 - Estimates photochemical efficiency of Photosystem II (PSII) from ratios of fluorescence levels




Minimum/*in vivo* fluorescence (F_0)

- Fluorescence in absence of photosynthetic light
- In the dark, limited electrons are used mostly for photosynthesis
- “Background” fluorescence measured



Maximum fluorescence (F_m)

- Fluorescence in absence photosynthesis
 - By high intensity, short wavelength flash of light
 - Electron acceptor plastoquinone (Qa) saturated with electrons (reduced) and closed reaction center
- Excess electrons emitted as fluorescence (max possible)



PhytoFlash

- 9 light emitting diodes (LEDs) (465 nm wavelength peak) arranged circular that evenly saturates sample in optical cell
- 3 LEDs activated to determine minimum fluorescence
- 6 high intensity LEDs activated (actinic light) to determine max fluorescence



Fluorescence Ratio

- Variable chlorophyll fluorescence ($F_v = F_m - F_0$)
 - Difference between fluorescence intensities with closed and open reaction centers
 - Part of the absorbed light energy that would be used in photosynthesis if all reaction centers were in the open state
- Yield (F_v/F_m)
 - Quantum efficiency of primary photochemical reaction of photosynthesis/photochemical quenching (proxy for efficiency of PSII)
 - Algal activity
 - Provides sensitive indicator of cell health

*Fluorometer essentially measures the efficiency of PSII which is an indicator of cell health

High/low Risk



- Algal abundance (# of cells/mL) 10-50 μm size class
- Algal activity (ratio) health/viability
- Filter out $<10 \mu\text{m}$ if high risk (interference)

Measuring a Sample

<https://www.youtube.com/watch?v=wruSUZOFOQM>

Ballast Water Compliance Monitoring

- Monitoring
 1. Initial inspection
 2. Detailed inspection
 3. Indicative measure
 4. Direct measure of compliance

Ballast Water Compliance Monitoring

- Monitoring
 1. Initial inspection
 2. Detailed inspection
 3. **Indicative measure**
 4. Direct measure of compliance

Ballast Water Compliance Monitoring

- Monitoring
 1. Initial inspection
 2. Detailed inspection
 - 3. Indicative measure**
 4. Direct measure of compliance

Category	Limit for Discharge
Viable, size > 50 µm	< 10 cells/m ³
Viable, size 10-50 µm	< 10 cells/ml
<i>Vibrio Cholerae</i>	< 1 Colony Forming Units/100ml
<i>Escherichia Coli</i>	< 250 Colony Forming Units/100ml
Intestinal <i>Enterococci</i>	< 100 Colony Forming Units/100ml

IMO D-2 Regulations

Ballast Water Compliance Monitoring

- Monitoring
 1. Initial inspection
 2. Detailed inspection
 - 3. Indicative measure**
 4. Direct measure of compliance

Category	Limit for Discharge
Viable, size > 50 µm	< 10 cells/m ³
Viable, size 10-50 µm	< 10 cells/ml
<i>Vibrio Cholerae</i>	< 1 Colony Forming Units/100ml
<i>Escherichia Coli</i>	< 250 Colony Forming Units/100ml
Intestinal <i>Enterococci</i>	< 100 Colony Forming Units/100ml

IMO D-2 Regulations

Ballast Water Compliance Monitoring

- Monitoring
 1. Initial inspection
 2. Detailed inspection
 - 3. Indicative measure**
 4. Direct measure of compliance

Category	Limit for Discharge
Viable, size > 50 μm	< 10 cells/m ³
Viable, size 10-50 μm	< 10 cells/ml
<i>Vibrio Cholerae</i>	< 1 Colony Forming Units/100ml
<i>Escherichia Coli</i>	< 250 Colony Forming Units/100ml
Intestinal <i>Enterococci</i>	< 100 Colony Forming Units/100ml

IMO D-2 Regulations

- Indicative measurements (10-50 μm cells)
 - Ideal sample volume
 - Methods simple, quick, no reagents needed
 - Respond to all treatment technologies (chlorination, UV)

IMO Ballast Water Regulations



- Ballast Water Management Convention 2004, 2017
- Vessel-specific Ballast Water and Sediments Management Plan
- Ballast Water Record Book
- International Ballast Water Management Certificate
- D-1 Regulations: ballast water exchange standard
 - ≥ 200 nautical miles from shore AND ≥ 200 m deep
 - Flow-through 3x vol of each ballast tank OR $\geq 95\%$ volumetric exchange
- D-2 Regulations: ballast water performance standard

Category	Limit for Discharge
Viable, size $> 50 \mu\text{m}$	$< 10 \text{ cells/m}^3$
Viable, size $10\text{-}50 \mu\text{m}$	$< 10 \text{ cells/ml}$
<i>Vibrio Cholerae</i>	$< 1 \text{ Colony Forming Units/100ml}$
<i>Escherichia Coli</i>	$< 250 \text{ Colony Forming Units/100ml}$
Intestinal <i>Enterococci</i>	$< 100 \text{ Colony Forming Units/100ml}$

Hawai`i



- Vessel-specific Ballast Water Management Plan
- Mid-ocean ballast water exchange or retain all ballast water on board
- Submit a ballast water reporting form to DLNR 24 hours prior to arrival

References

Shluker, A. D. (2003). State of Hawai'i Aquatic Invasive Species Management Plan. Prepared for Department of Land and Natural Resources, Division of Aquatic Resources

International Maritime Organization (2017). International Convention for the Control and Management of Ships' Ballast Water and Sediments (BWM). Retrieved from [http://www.imo.org/en/About/Conventions/ListOfConventions/Pages/International-Convention-for-the-Control-and-Management-of-Ships%27-Ballast-Water-and-Sediments-\(BWM\).aspx](http://www.imo.org/en/About/Conventions/ListOfConventions/Pages/International-Convention-for-the-Control-and-Management-of-Ships%27-Ballast-Water-and-Sediments-(BWM).aspx)

Turner Designs. (2017). Ballast-Check 2 Handheld PAM Fluorometer. Retrieved from <http://www.turnerdesigns.com/products/fluorometers-for-ballast-water-applications/ballast-check-handheld-fluorometer>

Younan, L. & Brown, C. (2017). California & Ballast Water Compliance Protocols. Retrieved from [http://www.imo.org/en/About/Conventions/ListOfConventions/Pages/International-Convention-for-the-Control-and-Management-of-Ships%27-Ballast-Water-and-Sediments-\(BWM\).aspx](http://www.imo.org/en/About/Conventions/ListOfConventions/Pages/International-Convention-for-the-Control-and-Management-of-Ships%27-Ballast-Water-and-Sediments-(BWM).aspx)